

M

Like our other collections, the >COLOURS palma< collection is made of solid premium WPC. Since the groove in this collection has a slightly different shape than our other boards, the >COLOURS palma< collection has black coloured clips that are only used for this colour. Please also note the following differences for installing the >COLOURS palma< collection.

1. Clip system for the >COLOURS palma< collection

Select clip

The boards are pushed into the clip using hand pressure. The distance between the boards is determined by the enclosed spacer, so there is some space in the bracket for expansion of the board.

Subsequent loosening of board connections

If planks are to be removed, it must be possible to loosen them. Using a long bit, you can lift them out and affix individual boards again even after the completed installation. Simply loosen the screws in the clamps along the board and lift the two boards upwards [Fig. 2]. Then insert the boards again.

For reinsertion, the clips are attached to one of the two already laterally inserted boards. The second board is carefully threaded into it and pressed down onto the substructure. Then simply tighten it again.

Note: In this variation, the last board can also be mounted on a surface with concealed end clamps.

Select edge clip

For affixing the first and last planks to the substructure. The screw connection with the substructure may be vertical from above at the starting point, and at the end point usually at an angle via the board into the substructure [see Fig. 3].

3. Installing the >COLOURS palma< collection using screws

For the >COLOURS palma< collection, we recommend installing it with the clip system. It is also possible to install it using screws. However, for larger surfaces or differing board lengths, we recommend prior consultation with MYDECK consulting personnel.

- When using screws for visible affixing of solid planks, the substructure must never be firmly connected to the surface and must always be installed as per floating method.
- Always pre-drill and sink.
- Place two screws per board support point.
- Min. distance to the board end: 50 mm / Min. joint distance between the boards: 5 mm
- Edge distance to side screws: 20-25 mm

Please note the max. edge protrusion of the >COLOURS palma< collection: 20 mm

